


N7

Ride on Floor Scrubber

Parts Manual




To view, print or download the parts manual,
visit: the parts manual, visit:

www.pennonenv.com


Address: 318 Xinghe Road, Yuyue Town, Deqing County, Huzhou
City, Zhejiang Province

Fig. 1 -RECOVERY TANK GROUP




Ref.	Part No.	Description
1	01040001	Screws, 6*16
2	0101020063	Warning light
3	0101020081-1	Sheet Metal
4	0101020047	Recovery Tank Cover
5	0101020054	vacuum hose, black, 80mm
6	0101020081-2	Sheet Metal,Adaptor, Hose
7	0101020081-3	Sheet Metal,motor cover, plate
8	01040014	Screws, 8*24
9	0101020015	Gasket/Sealing strip
10	01040152	Screws, 8*16
11	01040024	Screws, M6
12	0101020081-4	Sheet Metal,Bracket
13	01040014	Screws, 8*24
14	01040020	Screws, M6
15	01040016	Screws, 6*18
16	0101020107	Suction Motor

Fig. 2 -RECOVERY TANK GROUP




Ref.	Part No.	Description
1	0101020081-5	Sheet Metal,Hinge Wldt, Cover
2		Screws
3	0101020081-HRT	Sheet Metal,Hinge, Leaf, recovery tank
4	010102047	Recovery tank cover
5	0101020063	Warning light
6	0101020046	Recovery tank
7	0101020081-6	Sheet Metal,plate
8	01040014	Screws, 8*24
9	01040019	Screws, M8
10	0101020081-7	Sheet Metal
11	0101020081-8	Sheet Metal
12	01040004	Screws, 8*20

Fig. 3 -STEERING GROUP




Ref.	Part No.	Description
1		Screws
2	0101030160	Row lamp
3	0101030160-1	lamp plate
4		Screws

Fig. 4 -STEERING GROUP




Ref.	Part No.	Description
1	0101020086	Panel
2	0101020085	Gasket, Panl, Instmt
3	0101020081-9	Sheet metal, Shaft, Steering, Wheel
4	0101020104	Hole plug T36.3mm
5	01020030	Spare part, uc9.5mm
6	0101020022	Bellows, Shaft, Steering
7	0101020004	Wheel, Steering,
8	0101020081-10	Sheet Metal, Support Wldt, Steering
9	0101020081-11	Sheet Metal, Frame
10	0101020017	Front Drive Motor
11	0101020016	Steer, Control Assy, Wheel Drive
12	0101020050	Column, Steering
13	0101020012	Joint

Fig. 5 -SEAT GROUP




Ref.	Part No.	Description
1	0101020014-L	Left side of seat track
2	0101020014	Seat
3	0101020032	Cup
4	0101020081-12	Sheet Metal,cup holder
5	0101020014-R	Right side of seat track
6	0101050013	Battery
7	0101020081-13	Sheet Metal, Angle, Sppt, Battery
8	0101020081-14	Sheet Metal, Tray, Battery
9	0101020081-15	Sheet Metal, Stable, Battery
10	0101020048	Battery box
11		Storage box
12	0101020084	Controller
13	0101020083	Push rod motor
14	0101020081-16	Sheet Metal, controller
15	0101020081-17	Sheet Metal, controller
16	0101020081-18	Sheet Metal, Seat

Fig. 6 -MAIN FRAME GROUP




Ref.	Part No.	Description
1	0101020081-19	Sheet Metal,bracket
2		Screws, 12*45
3		Screws, 12*100
4	0101020081-BC	Sheet Metal,Head, Scb,
5	01040026	Screws, M12
6		Screws
7		Screws
8		Screws
9		Screws
10	0101020081	Sheet Metal, Frame

Fig. 7 -DISK SCRUB HEAD DRIVE MOTOR GROUP




Ref.	Part No.	Description
1		Knob, M8
2	0101020082	Brush Motor
3	0101020133	Flange(Magnetic)
4	0101020081-BC	Sheet Metal,Head, Scb,
5	0101020134	Brush(Magnetic)
6	0101020081-20	Sheet Metal, Squeegee Assy, Side
7	0101020099-R	Water blocking adhesive strip (right)
8	0101020099-F	Water blocking adhesive strip (front)
9	0101020099-L	Water blocking adhesive strip (left)
10	0101020081-20	Sheet Metal, Squeegee Assy, Side
11	0101020081-21	Sheet Metal, Bracket, Wheel
12	0101010038	Anti-collision wheel

Fig. 8 -FRONT GROUP




Ref.	Part No.	Description
1	0101020056	Hinge
2	0101020081-22	Sheet metal L, shaped fixed water tank
3	0101020081-23	Sheet metal L, shaped fixed battery
4	0101020081-24	Sheet metal, Battery, plate
5	0101020081-25	Sheet metal L, shaped fixed battery
6	0101020081-26	Sheet metal parts
7	0101020051	Accelerator
8	0101020081-27	Sheet metal parts , accelerator pedal
9	0101020021	clean water tank
10	0101020081	Sheet Metal,Frame
11	01010001	Water level line
12	0101010022	Clear water tank cover

Fig. 9 -TANKS DRAIN GROUP




Ref.	Part No.	Description
1	0101020081-28	Sheet Metal, Bracket
2	0101020097	Filter, Panl, Dust
3	0101010017	Clip,sewage pipe
4		Screws
5		Screws
6	0101020006	Sewage pipe
7	0101020005	Suction pipe
8	0101020007	Clear water pipe
9	0101020056	Hinge
10	0101020046	Recovery Tank

Fig. 10 -HOSE GROUP




Ref.	Part No.	Description
1	0101020009	Water pipe, 10*16
2	0101020027	Screws, 14*10*10
3	01020050	Clip, 16*25
4	0101010031	Solenoid valve
5	01020063	Screws, 4*14
6	0101010032	Clear water filter
7	01010002	Water pipe
8	01020064	Screws, 4*14, 90°

Fig. 11 -REAR SQUGGEGG LIFT GROUP



Ref.	Part No.	Description
1		Screws, 12*100
2	0101020110	Bushing, Flex, Ure
3		Screws
4	01020052	Screws, 20*3
5		Pad
6	0101020081-29	Sheet Metal, Channel, Arm, Lower Sqge
7		Screws
8	0101020083	Actuator motor
9	0101020121	Housing, Spring, Sqge Actuator
10		Screws
11	01020051	Screws, 2.8*19*122
12	0101020081-30	sheet metal, Bracket, Wheel

Fig. 12 -Squeegee Group, 1000mm



Ref.	Part No.	Description
1	0101010038	Anti-collision wheel
2		Knob, M10
3		Knob, M8
4		Screws
5		Sheet Metal, Bracket
6	0101020091	wheel, squeegee
7		Blade, squeegee
8		Retainer, Sqge
9	0101020106-R	Blade, Sqge, Rear
10		Squeegee Kit
11	0101020106-F	Blade, Sqge, Front