

BAR LPM	20	30	40	50	60	70	80	90	100	110	120	130	140	150	160	170	180	190	200	210	220	230	240	250							
10	2.2 (15)	2.0 (15)	1.8 (13)	←	1.7 (10)	←	←	1.6 (075)	←	1.5 (07)	1.4 (07)	←	←	←	←	←	1.3 (05)	←	←	←	←	←	←	←							
11	←	2.2 (15)	2.0 (15)	1.9 (13)	1.8 (13)	1.7 (10)	←	←	1.6 (075)	←	←	1.5 (07)	1.4 (07)	←	←	←	←	←	←	1.3 (05)	←	←	←	←							
12	←	2.2 (15)	2.1 (15)	2.0 (15)	1.9 (13)	1.8 (13)	1.7 (10)	←	←	←	1.6 (075)	←	←	1.5 (07)	←	←	←	←	←	←	←	←	←	1.3 (05)							
13	←	←	2.2 (15)	2.1 (15)	1.9 (13)	←	1.8 (13)	←	←	1.7 (10)	←	←	1.6 (075)	←	←	1.5 (07)	←	←	1.4 (07)	←	←	←	←	←							
14	←	←	2.2 (15)	2.1 (15)	2.0 (15)	1.9 (13)	←	←	1.8 (13)	←	←	←	1.6 (075)	←	←	←	←	←	1.5 (07)	←	←	←	1.4 (07)	←							
15	←	←	←	2.2 (15)	2.1 (15)	2.0 (15)	1.9 (13)	←	←	1.8 (13)	←	←	1.7 (10)	←	←	←	1.6 (075)	←	←	←	←	←	1.5 (07)	←	1.4 (07)						
16	←	←	←	←	2.2 (15)	2.1 (15)	2.0 (15)	←	←	1.9 (13)	1.8 (13)	←	←	1.7 (10)	←	←	←	←	1.6 (075)	←	←	←	←	←							
18	←	←	←	←	←	2.3 (20)	2.2 (15)	2.1 (15)	←	←	2.0 (15)	←	1.9 (13)	←	1.8 (13)	←	←	1.7 (10)	←	←	←	←	←	1.6 (075)							
19	←	←	←	←	←	2.3 (20)	2.3 (20)	2.2 (15)	2.1 (15)	←	←	2.0 (15)	←	1.9 (13)	1.8 (13)	←	←	←	1.7 (10)	←	←	←	←	←							
20	←	←	←	←	←	←	2.8 (3x075)	2.5 (3x07)	2.4 (3x06)	2.3 (3x06)	2.2 (3x05)	←	←	2.1 (3x05)	←	←	2.0 (3x05)	←	←	1.9 (13)	←	←	←	1.7 (10)	←						
21	←	←	←	←	←	←	←	2.8 (3x075)	2.5 (3x07)	2.4 (3x06)	2.3 (3x06)	2.2 (3x05)	←	←	2.1 (3x05)	←	←	2.0 (3x05)	←	←	1.9 (13)	←	←	←	1.8 (13)	←	←	1.7			
22	←	←	←	←	←	←	←	←	2.8 (3x075)	2.5 (3x07)	2.4 (3x06)	2.3 (3x06)	←	←	2.2 (3x05)	←	←	2.1 (3x05)	←	←	2.0 (3x05)	←	←	←	1.9 (13)	←	←	1.8 (13)			
24	←	←	←	←	←	←	←	←	←	2.8 (3x085)	2.8 (3x075)	2.5 (3x07)	←	←	2.4 (3x06)	2.3 (3x06)	←	←	2.2 (3x05)	←	←	←	←	←	1.9 (13)	←	←	1.8 (13)			
26	←	←	←	←	←	←	←	←	←	←	2.8 (3x10)	2.8 (3x085)	2.8 (3x075)	←	←	2.5 (3x07)	2.4 (3x06)	2.3 (3x06)	←	←	2.2 (3x05)	←	←	←	←	2.0 (3x05)	←	←	1.9 (13)		
28	←	←	←	←	←	←	←	←	←	←	←	2.8 (3x10)	2.8 (3x085)	2.8 (3x075)	←	←	2.5 (3x07)	←	←	2.4 (3x06)	2.3 (3x06)	←	←	←	←	2.2 (3x05)	←	←	2.1 (3x05)		
30	←	←	←	←	←	←	←	←	←	←	←	←	2.8 (3x10)	2.8 (3x085)	2.8 (3x075)	←	←	2.5 (3x07)	←	←	2.4 (3x06)	←	←	←	←	2.3 (3x06)	←	←	2.2 (3x05)		
32	←	←	←	←	←	←	←	←	←	←	←	←	←	2.8 (3x10)	2.8 (3x085)	2.8 (3x075)	←	←	2.5 (3x07)	←	←	2.4 (3x06)	←	←	←	←	2.3 (3x06)	←	←	2.2 (3x05)	
34	←	←	←	←	←	←	←	←	←	←	←	←	←	←	2.8 (3x10)	2.8 (3x085)	2.8 (3x075)	←	←	2.5 (3x07)	←	←	2.4 (3x06)	←	←	←	←	2.3 (3x06)	←	←	2.2 (3x05)
36	←	←	←	←	←	←	←	←	←	←	←	←	←	←	←	2.8 (3x10)	2.8 (3x085)	2.8 (3x075)	←	←	2.5 (3x07)	←	←	←	←	←	←	←	←	2.4 (3x06)	
38	←	←	←	←	←	←	←	←	←	←	←	←	←	←	←	←	2.8 (3x10)	2.8 (3x085)	2.8 (3x075)	←	←	2.5 (3x07)	←	←	←	←	←	←	←	←	2.4 (3x06)
40	←	←	←	←	←	←	←	←	←	←	←	←	←	←	←	←	←	2.8 (3x10)	2.8 (3x085)	2.8 (3x075)	←	←	←	←	←	←	←	←	←	←	2.5 (3x07)

ST75

ST76

HOW TO READ THE CHART

- Select the flow of the pump from the vertical column on the left hand side.
- Follow the row across until you are in the same vertical column as the pressure of your pump.
- In the relevant box will be the following info:
Injector Nozzle Size
(ST75/ST76 Foam Lance Nozzle Size(s))
- Select the Suttner injector to suit the above